

HF-DES Protocol Comparison

Command Telegrams from PC/PLC to RFID Device

| HF-Series | | | DESFire-Series | | |
|-------------|-------------------|--------------------|----------------|-------------------|--------------------|
| Length | Description | Value | Length | Description | Value |
| 1 Byte | Start of Telegram | 0xAA (fixed value) | 1 Byte | Start of Telegram | 0x50 (fixed value) |
| 1 Byte | Device Address | 0x00...FF | – | – | – |
| 1 Byte | Length | 0x00...FF | 2 Bytes | Length | 0x00...FF |
| 1 Byte | Command Code | 0x00...FF | 1 Byte | Command Code | 0x00...FF |
| 0...n Bytes | Data | 0x00...FF | 0...n Bytes | Data | 0x00...FF |
| 1 Byte | Checksum | 0x00...FF | 1 Byte | Checksum | 0x00...FF |
| 1 Byte | End of Telegram | 0xBB (fixed value) | – | – | – |

Reply Telegram from RFID Device to PC/PLC

| HF-Series | | | DESFire-Series | | |
|-------------|-------------------|--------------------|----------------|----------------------|---------------------------|
| Length | Description | Value | Length | Description | Value |
| 1 Byte | Start of Telegram | 0xAA (fixed value) | 1 Byte | Start of Telegram | 0x50 / 0F0 (fixed values) |
| 1 Byte | Device Address | 0x00...FF | – | – | – |
| 1 Byte | Length | 0x00...FF | 2 Bytes | Length | 0x00...FF |
| – | – | – | 1 Byte | Command Code | 0x00...FF |
| 1 Byte | Status | 0x00...FF | – | – | – |
| 0...n Bytes | Data | 0x00...FF | 0...n Bytes | Data or Error Status | 0x00...FF |
| 1 Byte | Checksum | 0x00...FF | 1 Byte | Checksum | 0x00...FF |
| 1 Byte | End of Telegram | 0xBB (fester Wert) | – | – | – |

Request of Firmware Version

| | |
|---------------------|------------------|
| 0xAA 00 01 86 87 BB | 0x50 00 00 04 54 |
|---------------------|------------------|