

OEM-DESFire Series

13.56 MHz OEM RFID Module

Demo Software Manual

iDTRONIC GmbH
Ludwig-Reichling-Straße 4
67059 Ludwigshafen
Germany/Deutschland

Issue 0.6

– 07. November 2024 –

Phone: +49 621 6690094-0
Fax: +49 621 6690094-9
E-Mail: info@idtronic.de
Web: idtronic.de

Subject to alteration without prior notice.
© Copyright iDTRONIC GmbH 2024
Printed in Germany

Contents

1	Operation Examples	4
1.1	USB Driver Installation	4
1.2	Driver Installation PC/SC.....	4
1.3	Software Screen Overview.....	4
2	Connect with Device.....	5
2.1	Establishing Connection (VCP)	5
2.2	Establishing Connection (Ethernet)	5
2.3	Establishing Connection (PC/SC).....	5
2.4	Reading Firmware Version and Hardware Serial Number	6
3	Software Functions in Detail	7
3.1	Tab "System"	7
3.1.1	Changing The Baudrate.....	7
3.1.2	IO Commands	7
3.1.3	Address Configuration	7
3.1.4	Antenna Selection.....	7
3.1.5	Service Function (not intended for end-customers).....	7
3.1.6	Configure Ethernet Interface	7
3.2	Tab "AUTOLIST CARDS"	9
3.3	Tab "ISO1443A-3/4"	9
3.4	Tab "MIFARE Classic"	10
3.5	Tab"Ultralight/C"	11
3.6	Tab "DESFire"	11
3.7	Tab "ISO 14443B"	12
3.8	Tab "ISO15693"	13
3.9	Tab "ISO7816".....	13
3.10	Tab "ISO18000"	14
3.10.1	Overview.....	14
3.10.2	Write 1 Block of Data in Block 0x0004.....	15
3.10.3	Read All Blocks, New Data at Block 0x0004	16

1 Operation Examples

1.1 USB Driver Installation

If the device is connected to a PC for the first time, it can take some time for automatic installation VCP driver. If this is the case, pls. wait until this is fully done.

In rare cases it is possible, that automatic installation fails. Then perform a manual installation.

You can download the latest drivers here: <https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers>

The NEO2 family used a different USB IC: https://www.wch-ic.com/downloads/CH341SER_EXE.html


1.2 Driver Installation PC/SC

Support for PC/SC is part of Windows OS. The automatic installation of the device driver takes much longer than for the serial interface (VCP). If you plug in the device for the first time, please wait until all processes finish.

If you place an RFID tag to a PC/SC device for the first time, further drivers need to be installed.

Please be patient until this is finished.


1.3 Software Screen Overview



2 Connect with Device

2.1 Establishing Connection (VCP)


Plug in the RFID device first, then start the demo software.



The factory default setting for DESFire devices is 115200 Baud.

Establish the connection with [Connect]. Please pay attention to the status message on the Protocol Screen at the bottom of this software.


2.2 Establishing Connection (Ethernet)



Step 6 is to check the function of the connection.

2.3 Establishing Connection (PC/SC)


Checkmark "PC/SC" and select your device from the pull down menu "COMPORT".



Note

PC/SC devices can have a static mode (connection is always possible) or dynamic mode (connection is only possible with a suitable tag in read range). The static mode is not supported by all firmware versions.

2.4 Reading Firmware Version and Hardware Serial Number



You can do this after every click on [CONNECT] to check if the connection is really working.

3 Software Functions in Detail

3.1 Tab “System”

3.1.1 Changing The Baudrate

If you have a NEO2 then DO NOT change the Baudrate using this function!

BAUDRATE	9600	BPS	SET BAUDRATE
----------	------	-----	--------------

3.1.2 IO Commands

Some devices have hardware to react to LED and Buzzer commands.

LED	LIGHTING TIME	3	x50MS	NO. OF TIMES	4	LIGHTING
BUZZER	BEEPING TIME	3	x50MS	NO. OF TIMES	4	BEEPING
NOTE: EACH CYCLE TIME IS FIXED TO 500MS!						

3.1.3 Address Configuration

This function is only available in the version for RS485 devices. The standard demo software does not provide this function.

ADDRESS	0	NOTE: THIS OPTION FOR SET RS485 DEVICES ADDRESS!	SET ADDRESS
---------	---	--	-------------

3.1.4 Antenna Selection

This will only work with devices that operate several antennas.

ANT PORT	1	NOTE: DEFAULT ANTENNA STATUS IS OPENED!	SET ANT
----------	---	---	---------

After a cold boot, the antenna #1 will be selected with multi-antenna devices.


3.1.5 Service Function (not intended for end-customers)

ADDRESS	0x00000010		READ FLASH
ADDRESS	0x00000008		WRITE FLASH
NOTE: ADDRESS AS 32BIT, MSB FIRST!			
GET ANT			

3.1.6 Configure Ethernet Interface

The screenshot shows the HF DEMO V5.1 software window. The menu bar includes FILE, PC/SC CHANNEL, ABOUT, and EXIT. The top navigation bar has tabs for SYSTEM, AUTOLIST CARDS, ISO14443A-3/4, MIFARE CLASSIC, ULTRALIGHT/C, DESFIRE, ISO14443B, ISO15693, ISO7816, and ISO18000. The CONNECTIVITY section contains checkboxes for CONNECTION (PC/SC, SERIAL, TCP/IP), COMPORT (set to COM1), BAUDRATE (set to 115200), ADDRESS (set to 0), IP ADDRESS (set to 192.168.10.148), PORT (set to 8000), SEARCH IP, IP MODIFY, and DISCONNECT buttons.

After the connection is established, click on [IP MODIFY]. This will open a dialog box to configure the Ethernet interface.




The standard setting of the socket type is TCP Server. This means that a control software connects with the RFID device. The connection is made with the Local Port.

If the reader automatically reads data from a tag, you can configure the RFID device as TCP Client. After reading the data, I will connect with the IP address configured in remote host and use the remote port so deliver the data.



You can also configure the Ethernet interface via the web interface or with the software "S2E ConfigTool_V1.4.exe".


3.2 Tab "AUTOLIST CARDS"



This tab is to send continuous commands to detect tags. Use this tab to detect the tag type.

This is not a configuration tab for the explicit auto-list cards configuration command 0x23.


3.3 Tab "ISO1443A-3/4"





Active-IDLE= Send REQ, Anticollision, select, this will only work with cards that are NOT halted.

Active-ALL = Send WUPA , Anticollision, select, this will work with all cards.


3.4 Tab “MIFARE Classic”



If you have detected a Mifare Classic card with [ACTIVE-IDLE] or [ACTIVE-ALL], you can click on [READ ALL BLOCKS] to read out all accessible memory blocks or on [E-WALLET] to check the payment functions for Mifare Classic.




3.5 Tab "Ultralight/C"




If you need to access further Ultralight functions, refer to the tag's manual and use the APDU channel to send manufacturer-specific commands directly to the RFID tag.


3.6 Tab "DESFIRE"




The memory of a DESFire RFID tag is organized as a computer memory. You can have folders, which are called "Applications". Access the Application management by click on the button [PICC LEVEL].




After you have selected or created an Application, you can open the file management by click on the button [APPLICATION LEVEL] in the main screen.



3.7 Tab "ISO 14443B"




3.8 Tab "ISO15693"




Note: You can only select the flag values 0x02 and 0x22. Some tags need other flags set for write operations (e.g. Tag-it).

3.9 Tab "ISO7816"




3.10 Tab "ISO18000"

3.10.1 Overview



3.10.2 Write 1 Block of Data in Block 0x0004



Important Note

The I-Code ILT-M supports to write only 1 block at once using this command.

3.10.3 Read All Blocks, New Data at Block 0x0004

