



**OEM LF1S Devices**  
**LF RFID OEM Module**  
**Communication Protocol**  
**Tag Types: Read-only, Hitag 1, Hitag S, FDX-B, ID Card**

Date	Version	Description
2018-09-04	5.1	Layout changed, updated to newer FW version that combined Hitag 1 with Hitag S, removed Hitag 2, added further tag types

iDTRONIC GmbH  
Ludwig-Reichling-Straße 4  
67059 Ludwigshafen  
Germany/Deutschland

Issue 5.1  
– 04. September 2018 –

Phone: +49 621 6690094-0  
Fax: +49 621 6690094-9  
E-Mail: [info@idtronic.de](mailto:info@idtronic.de)  
Web: [idtronic.de](http://idtronic.de)

Subject to alteration without prior notice.  
© Copyright iDTRONIC GmbH 2018  
Printed in Germany

# Contents

- 1 Protocol Description.....4
  - 1.1 Default Baudrate .....4
  - 1.2 Data Package Format.....4
  - 1.3 Byte Description in Data Package .....4
  - 1.4 Command List.....5
- 2 System Commands .....6
  - 2.1 Get\_VersionNum (0x51) .....6
  - 2.2 BUZ\_control (0x52).....6
  - 2.3 LED\_control (0x53) .....6
  - 2.4 SET\_ANT (0x54) .....7
- 3 Command for read-only Data Tag.....8
  - 3.1 EM4100/4200\_GetUID (0x57).....8
- 4 Hitag S Commands .....9
  - 4.1 Hitag1/S\_Request (0x58) .....9
  - 4.2 Hitag1/S\_Select (0x59) .....9
  - 4.3 Hitag1/S\_Quiet (0x5C) .....9
  - 4.4 Hitag1/S\_ReadPage (0x5A) .....10
  - 4.5 Hitag1/S\_WritePage (0x5B) .....10
  - 4.6 Hitag1/S\_LockPage (0x60) .....10
- 5 Commands for FDX-B Data Tags .....12
  - 5.1 Read FDX-B tag/card (ISO11784/85) (0x56) .....12
  - 5.2 Format Hitag S tag into FDX-B (0x5D) .....12
  - 5.3 Format Hitag S cards into ID card (0x5E) .....12

## 1 Protocol Description

### 1.1 Default Baudrate

Baudrate	Data Bits	Start Bits	Stopp Bits	Checksum
9600 bps	8	1	1	None

### 1.2 Data Package Format

Data package format, command package is sent from Host to Reader, response package returned from Reader to Host

#### CMD package format (Host to Reader)

STX	STATION ID	DATA LENGTH	CMD	DATA [0..N]	BCC	ETX
-----	------------	-------------	-----	-------------	-----	-----

(BCC) = STATION ID ⊕ DATALENGTH ⊕ CMD ⊕ DATA [0] ⊕ ... ⊕ DATA [n], where ⊕ is the “EOR”.

#### Response package format (Reader to Host)

STX	STATION ID	DATA LENGTH	STATUS	DATA[0..N]	BCC	ETX
-----	------------	-------------	--------	------------	-----	-----

(BCC) = STATION ID ⊕ DATA LENGTH ⊕ STATUS ⊕ DATA [0] ⊕ ... ⊕ DATA [n], where ⊕ is the “EOR”.

### 1.3 Byte Description in Data Package

Field	Length	Description	Remark
STX	1	0xAA: 'start byte' – standard control byte, means the start of one data package.	0xAA = 0b1010.1010
STATION ID	1	Device address, necessary in multiple device communicating, when reader receive data package, it will judge the inner address if match up with itself preset, only response when match up	Address 0x00 is the special address only used under Single mode, reader will response any data package with 0 address(no address judge).
DATALENGTH	1	Data byte length in data package, including CMD/STATUS and DATA field, but no BCC. LENGTH= numbers of byte (CMD/STATUS + DATA[0..N])	
CMD	1	Command byte: compose with one Cmd byte	Only used in Send package
STATUS	1	Return status byte: status return from Reader to Host	Only used in Return package
DATA [0-N]	0–241	This is a data flow related to Length and CMD byte. Some part of commands no need additional data	
BCC	1	8bits checksum byte, including all bytes XOR checksum besides STX, ETX	
ETX	1	0xBB: ' stop byte' – standard control byte, means end of data package	0xBB = 0b1011.1011

## 1.4 Command List

CMD	Name	Description
<b>System Commands</b>		
0x51	Get_VersionNum	To get device hardware version number
0x52	BUZ_control	Buzzer control
0x53	LED_control	LED control
0x54	SET_ANT	To open or close antenna
<b>Command for read-only Data Tags</b>		
0x57	EM4100/4200_GetUID	Get UID from read-only tag
<b>Commands for Hitag-1 + Hitag S Data Tags</b>		
0x58	Hitag1/S_Request	Request card
0x59	Hitag1/S_Select	Select card
0x5C	Hitag1/S_Quiet	Card quiet
0x5A	Hitag1/S_ReadPage	Read data per page
0x5B	Hitag1/S_WritePage	Write data per page
0x60	Hitag1/S_LockPage	Lock page
<b>Commands for further Data Tags</b>		
0x56	Read FDX-B	Read FDX_B Data Tag (ISO11784/85)
0x5D	Format to FDX-B	Format Hitag S Tag for operation as an FDX-B
0x5E	Format to ID Card	Format Hitag S Tag for operation as an ID Card

### IMPORTANT NOTE

**Only Modules with Designation  
LF1S support Hitag 1 + Hitag S.**

## 2 System Commands

### 2.1 Get\_VersionNum (0x51)

#### Send Data

None

#### Reply with Success

STATUS: 0x00 – OK  
DATA[0~5]: VersionNum

#### Reply in Case of Error

STATUS: 0x01 – FAIL  
DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 01 51 50 BB  
Reply from RFID device to PC/PLC: AA FF 07 00 48 69 74 61 67 53 F8 BB  
Note: 48 69 74 61 67 53 is the hardware version number

### 2.2 BUZ\_control (0x52)

#### Send Data

DATA[0]: Buzzer control time, unit as ms 0x00 ... 0xFF

#### Reply with Success

STATUS: 0x00 – OK  
DATA: None

#### Reply in Case of Error

STATUS: 0x01 – FAIL  
DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 02 52 64 34 BB (BUZ beeping 100 ms)  
Reply from RFID device to PC/PLC: AA FF 01 00 FE BB (confirmation)

### 2.3 LED\_control (0x53)

#### Send Data

DATA[0]: LED number 0x00 = LED1  
0x01 = LED2  
DATA[1]: LED control time, unit as ms 0x00 ... 0xFF

#### Reply with Success

STATUS: 0x00 – OK  
DATA: None

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

### Example

Command from PC/PLC to RFID device: AA 00 03 53 00 64 34 BB (control LED1 lighting 100 ms)

Reply from RFID device to PC/PLC: AA FF 01 00 FE BB

## 2.4 SET\_ANT (0x54)

### Send Data

DATA[0]: control flag                    0x00 = close antenna  
    0x01 ... 0xFF = open antenna

### Reply with Success

STATUS: 0x00 – OK

DATA: None

### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

### Example

Command from PC/PLC to RFID device: AA 00 02 54 00 56 BB Close antenna

Reply from RFID device to PC/PLC: AA FF 01 00 FE BB

Note: reader default is antenna opened after power up

### 3 Command for read-only Data Tag

#### 3.1 EM4100/4200\_GetUID (0x57)

##### Send Data

None

##### Reply with Success

STATUS: 0x00 – OK

DATA[0~4]: 5byte card UID

##### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

##### Example

Command from PC/PLC to RFID device: AA 00 01 57 56 BB

Reply from RFID device to PC/PLC: AA 00 06 00 01 0F C3 4E 30 B5 BB, among them 01 0F C3 4E 30 is card UID

## 4 Hitag S Commands

### 4.1 Hitag1/S\_Request (0x58)

#### Send Data

None

#### Reply with Success

STATUS: 0x00 – OK

DATA[0~3]: 4 byte card UID

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 01 58 59 BB

Reply from RFID device to PC/PLC: AA FF 05 00 31 1E 45 72 E2 BB, among them 31 1E 45 72 is card UID

### 4.2 Hitag1/S\_Select (0x59)

#### Send Data

DATA[0~3]: card UID

#### Reply with Success

STATUS: 0x00 – OK

DATA[0~3]: HitagS configured package data

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 05 59 31 1E 45 72 44 BB

Reply from RFID device to PC/PLC: AA FF 05 00 CA 00 00 AA 9A BB

Note: CA 00 00 AA is card configured package data

### 4.3 Hitag1/S\_Quiet (0x5C)

#### Send Data

None

#### Reply with Success

STATUS: 0x00 – OK

DATA: None

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

**Example**

Command from PC/PLC to RFID device: AA 00 01 5C 5D BB

Reply from RFID device to PC/PLC: AA FF 01 00 FE BB ,make card enter Quiet status

**4.4 Hitag1/S\_ReadPage (0x5A)****Send Data**

DATA[0]: page address

**Reply with Success**

STATUS: 0x00 – OK

DATA[0~3]: 4Byte card data

**Reply in Case of Error**

STATUS: 0x01 – FAIL

DATA: None

**Example**

Command from PC/PLC to RFID device: AA 00 02 5A 00 58 BB to read Page0

Reply from RFID device to PC/PLC: AA FF 05 00 31 1E 45 72 E2 BB

**4.5 Hitag1/S\_WritePage (0x5B)****Send Data**

DATA[0]: Page address

DATA[1~4]: 4Byte data

**Reply with Success**

STATUS: 0x00 – OK

DATA: None

**Reply in Case of Error**

STATUS: 0x01 – FAIL

DATA: None

**Example**

Command from PC/PLC to RFID device: AA 00 06 5B 3F 00 01 02 03 62 BB

Write data of 00 01 02 03 into Page 3F of HitagS 2048 card

Reply from RFID device to PC/PLC: AA FF 01 00 FE BB

**4.6 Hitag1/S\_LockPage (0x60)****Send Data**

DATA[0]:	Lock page parameter	0x01 = Lock page 1
		0x02 = Lock page 2, page 3
		0x03 = Lock page 4, page 5
		0x04 = Lock page 6, page 7
		0x05 = Lock page 8, page 9, page 10, page 11
		0x06 = Lock page 12, page 13, page 14, page 15
		0x07 = Lock pages 16 – 23

0x08 = Lock pages 24 – 31  
0x09 = Lock pages 32 – 47  
0x0A = Lock pages 48 – 63

**Reply with Success**

STATUS: 0x00 – OK  
DATA: None

**Reply in Case of Error**

STATUS: 0x01 – FAIL  
DATA: None

**Example**

Command from PC/PLC to RFID device: AA 00 02 60 01 63 BB, Lock Page 1  
Reply from RFID device to PC/PLC: AA FF 01 00 FE BB

## 5 Commands for FDX-B Data Tags

### 5.1 Read FDX-B tag/card (ISO11784/85) (0x56)

#### Send Data

None

#### Reply with Success

STATUS: 0x00 – OK

DATA[0~11]: 12 Bytes card data, including 5 bytes national code + 2 bytes country code +1 byte data mark +1 byte animal tag mark+ 3 bytes customized data

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 01 56 57 BB

Reply from RFID device to PC/PLC: AA 00 0D 00 00 00 00 00 00 00 00 01 01 00 00 00 0D BB

### 5.2 Format Hitag S tag into FDX-B (0x5D)

#### Send Data

DATA[0]: lock flag(1 byte)

DATA[1-5]: national (5 byte)

DATA[6-7]: country code (2 bytes)

DATA[8-9]: animal flag(2 bytes)

DATA[10-12]: user data (3 bytes)

#### Reply with Success

STATUS: 0x00 – OK

DATA: none

#### Reply in Case of Error

STATUS: 0x01 – FAIL

DATA: None

#### Example

Command from PC/PLC to RFID device: AA 00 0E 5D 00 00 00 00 00 00 00 00 01 01 00 00 00 53 BB

Reply from RFID device to PC/PLC: AA 00 01 00 01 BB

### 5.3 Format Hitag S cards into ID card (0x5E)

#### Send Data

DATA[0] : lock flag(1 byte)

DATA[1-5]: EM4100 card Serial number (5 byte)

#### Reply with Success

STATUS: 0x00 – OK

DATA: none

**Reply in Case of Error**

STATUS: 0x01 – FAIL

DATA: None

**Example**

Command from PC/PLC to RFID device: AA 00 07 5E 00 10 00 00 00 01 48 BB

Reply from RFID device to PC/PLC: AA 00 01 00 01 BB